

NON – MAGNETIC FOOT BOARD



INSTRUCTIONS FOR USE HANDBOOK



REV.01/2015

WARNING

- 1) Always obey the LOAD CAPACITIES indicated on the nameplates (100-150kg) what also means do not go up by two people.
- **2)** Always check the SUITABILITY OF THE FLOOR on which to place the ladder. Avoid polished floors, made slippery by water, oils, fuels and the like.
- 3) The user must ALWAYS KEEPING WITH THE BODY IN THE CENTER OF STEPS holding hands
- **4)** FORBIDDEN LEAN OR PERFORM ANY WORK WITH LOADS or FAR SIDE FORCE IN THE CROSS, in case it is necessary, use a higher scale or move it to the position facing the point to be reached.
- **5)** USE SUITABLE FOOTWEAR that allow a secure support. DO NOT use clogs, slippers or rubber boots.
- 6) It is forbidden to make changes and / or repairs
- 7) They can not be made works in the vicinity of power lines that pass at a distance of less than 4 m.
- 8) BEFORE USING THE LADDER YOU MUST CHECK:
 - There aren't elements damaged, deformed or cracked
 - There is no presence permanent bending of pillars and steps.
 - The caps are not consumed for wear
 - Any locking devices are activated and working.

THE MANUFACTURER IS NOT AND 'RESPONSIBLE FOR ANY DAMAGE TO PERSONS OR PROPERTY WHICH MAY RESULT FROM IMPROPER USE, COMPLIANCE WITH RULES FROM ABOVE, OR THE ABSENCE OF PERIODIC MAINTENANCE CHECKS OR AGAINST ANY DAMAGES CAUSED BY. WE RECOMMEND CAREFUL CONTROL OF PARTS BEFORE EACH USE.

